

INSTALLATION INSTRUCTIONS

CB6133A



◆ General Information

Please inspect the product immediately upon receipt for transit damage, missing packs/parts or manufacturing fault. Damage reported later cannot be accepted. Please handle the product with care avoiding knocks and shock loading to all sides and edges of the glass.

Notes: Safety glass can not be re-worked.

Please read these instructions carefully before start of installation.

Special care should be taken when drilling walls to avoid hidden pipes or electrical cables.

Note: This product is heavy and may require two people to install.









Aftercare instructions

After use, your shower should be cleaned with soap and water. This is particularly important in hard water districts where insoluble lime salts may be deposited and allowed to build up. Cleaners of a gritty or abrasive nature should not be used. Care should be taken to avoid contact with strong chemicals such as organic solvents and strippers.


Glass cleaners can be used but with caution, if in doubt contact the manufacturer of the cleaner in question.

Please keep these instructions for aftercare and customer service details.


Tools Required
























This product is heavy and may require two people to install.



◆ Assembly Drawing



ITEM	PARTS DESCRIPTION	QUANT.
A	WALL JAMB	2
B	HEADER	1
C	BOTTOM TRACK	1
D	TOP FRAME	3
E	BOTTOM FRAME	3
F	SIDE FRAME	4
G	CORNER GUIDE	6
H	TOWEL BAR	2
I	RETAINER #1	1
J	RETAINER #2	1
K	MIDDLE FRAME	2
L	GASKET SEAL	1
M	PLASTIC GASKET	1
N	#6 X 1-1/2" SCREW	12
AA	#8 X 1-1/2" SCREW	6
BB	#8-32 X 3/8" SCREW	6
CC	#6 X 3/8" SCREW	4
DD	#6 X 3/4" SCREW	4
EE	WALL ANCHOR	6
FF	NYLON ROLLER	6
GG	BUMPER	2
HH	TOWEL BAR SUPPORT	4
II	PLASTIC GUIDE INSERT	4




◆ Installation Steps

STEP 1 - Bottom track installation


- I. Measure the opening along the tub or the shower base rim.
- II. Cut the bottom track (C) 11/16" (17.5 mm) shorter than the opening.

Attention: *Cut the end of the bottom track that is closest to the shower head, in order to have the notch on the opposite side.*



STEP 2 - Bottom track position


- I. Temporarily place the bottom track (C) on the tub or the shower base rim near as possible of the shower base exterior edge.
- II. Stand the wall jambs (A) vertically.
- III. With a pencil, mark the position of the bottom track for future reference.



STEP 3 - Wall jamb installation


- I. Level wall jamb (A).
- II. Mark it's position and drill the holes.

Drill bits: - Ceramic tile wall: 7/32" (5mm) carbide bit.
- Dry wall: 3/16" (4.8 mm)
- Plastic: 1/8" (3,2mm)
- III. Repeat for other wall jamb.




STEP 4 - Silicone application

- I. Caulk the bottom track (C) along its full length under the track.
- II. Place track in its correct position, using the reference mark made in step 2.
- III. Apply masking tape to allow silicone to dry.
- IV. Wipe away excess silicone.




STEP 5 - Fasten wall jambs

- I. Insert wall anchors (EE) and secure the wall jambs (A) with screws (AA).
- II. Insert the plastic gasket (M) on the inner side of the wall jamb (A) located on the side closest to the shower head.
- III. Insert gasket seal over (L) the central tab of the wall jamb (A).




STEP 6 - Header installation

- I. Measure the opening along the top of the wall jambs (A).
- II. Cut the header (B) 1/16" (2 mm) shorter than the opening along the top of the wall jambs.
- III. Install the header (B) over the wall jambs.



STEP 7 - Rollers installation


- I. Secure the rollers (FF) in the mid section of the graded grooves on the top frame (D) with screws (BB).
- II. If necessary adjust the levelling of your door by repositioning the rollers in the upper or lower grooves as required.
- III. Repeat these operations for each roller.



STEP 8 - Installation des panneaux

Note: The inside panel must be on the side closest to the shower head.

- I. From inside the tub, hang the exterior panel so that its rollers rest in the header (B) groove. Raise the panel slightly to position it onto the bottom track (C).
- II. Install middle and interior panels as shown on illustration.
- III. If required, adjust rolling of panels by repositioning the rollers as mentioned earlier in step 7.



STEP 9 - Plastic guides & retainers

- I. Insert the two plastic guides (II) into the slots provided on the retainer (FIG. A).
- II. Hook the retainer #1 (I) into the upper channel of the bottom track (C), and then into channel of the bottom frame (E) of the middle panel (FIG. B).
- III. Secure with screws (CC).
- IV. Repeat these operations for retainer # 2 (J) on the interior panel in the lower channel of the bottom track (C) (FIG. C).

FIG. A




FIG. B (#1)





FIG. C (#2)



STEP 10 - Towel bar supports

- I. Insert the tab of one of the towel bar supports (HH) into the notch of each door side frame (F) and rotate the towel bar support until it clicks into place.(FIG A).
- II. Slide the towel bar (H) over the supports and secure with the appropriate screws (D) (FIG B).
- III. Repeat with the other towel bar.




FIG. A





FIG. B

STEP 11 - Bumpers installation

- I. Place the self-adhesive bumpers (GG) at the top and bottom of the wall jamb (A).

Ensure that the side frame (F) of exterior panel make contact, with the bumpers (GG) when in closed position.



STEP 12 - Silicone application

- I. Apply silicone between the front lip of the wall jambs (A) and the bottom track (C).

Only apply silicone to the outside of the unit.

Do not obstruct the drainage notch on bottom track.

- II. Allow the caulking to set 24 hours before using the unit.

